



# TYGER ACCESS

TG-AS2F24009

Scan to Download the Latest Digital Version



## BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: [WWW.TYGERAUTO.COM/CONTACT](http://WWW.TYGERAUTO.COM/CONTACT)

## TORQUE VALUES



Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- x1** Driver/Left Tyger Access
- x1** Passenger/Right Tyger Access
- x2** Front Mounting Brackets [A]
- x4** Center and Rear Mounting Brackets [B]
- x6** Support Brackets [D]
- x18** Plastic Retainers
- x36** 8mm x 22mm OD x 2mm Flat washers
- x24** 8mm Nylon Lock Nuts
- x12** 8mm Lock Washers
- x12** 8-1.25mm x 25mm Hex Bolts

## Parts List

### Top View


**ATTENTION:** Refer to **D** and **P** labelling on the side of the tubes to determine Driver and Passenger TYGER Access




Reference the letters printed on the brackets to determine mounting locations

**Top View**

**D** Driver Side TYGER Access



**P** Passenger Side TYGER Access



**Bottom View**



**D** Driver Side TYGER Access




**P** Passenger Side TYGER Access



## TOOLS REQUIRED




(Fig 2) Attach Support Bracket **[D]** to the bottom two studs




(Fig 3) Attach Bracket **[A]** to upper rocker panel stud and Support Bracket **[D]** stud at the front mounting location

## STEP 1 MOUNTING BRACKETS

Follow (Fig 1 – 5) to attach the brackets to the Driver/Left Side. Ensure all hardware is hand tightened at this point.




### Driver-side Front Mounting Area




(Fig 1) Attached (3) Plastic Retainers on the front

### Driver-side Center & Rear Mounting Area



(Fig 4) At center and rear mounting location, attach Plastic Retainers to three studs, and then attach Support Bracket **[D]** to bottom two studs


- (1) Plastic Retainer
- (2) 8mm x 22mm Flat Washers
- (2) 8mm Nylon Lock Nuts



(Fig 5) Attach Bracket [B] to Support Bracket [D] and upper rocker panel stud at the center and rear mounting locations

## STEP 2 MOUNTING RUNNING BOARD


Follow (Fig 6) to install the Access Drop Step on the Driver/Left. **Ensure all hardware is hand tightened at this point.**



(Fig 6) Attach TYGER Access Drop Step to Mounting Brackets using indicated hardware


## STEP 3 PASSENGER SIDE

Repeat **STEPS 1-2** for passenger side installation.



## STEP 4

Ensure Access Drop Step is level and straightened, then **tighten all fasteners**. Installation is complete. Perform periodic inspections to the installation to make sure that all hardware is secure and tight.



Complete Installation