



TYGER FRONT BUMPER

TG-BP7T32428

BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES


Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- x1 TYGER Center Bumper
- x1 Winch Tray Assembly
- x1 Skid Plate
- x1 Bull Nose
- x1 Driver/left Mounting Bracket
- x1 Passenger/right Mounting Bracket
- x1 Driver/left Support Bracket
- x1 Passenger/right Support Bracket
- x1 License Plate Bracket
- x2 Plastic Plugs for License Plate
- x1 Foam for A/C line
- x4 Relocation Wedges
- x1 1700mm Edge Trim
- x10 Zip Ties (2.75 x 1 x 200)
- x2 6-1.0mm x 40mm Hex Bolts
- x3 8-1.25mm x 25mm Hex Bolts
- x2 10-1.5mm x 40mm Hex Bolts
- x2 12-1.25mm x 30mm Hex Bolts
- x6 12-1.75mm x 40mm Hex Bolts
- x2 6mm x 12mm x 1.6mm Flat Washers
- x14 8mm x 24mm x 2mm Flat Washers
- x4 10mm x 20mm x 2mm Flat Washers
- x4 10mm x 30mm x 2.5mm Flat Washers
- x8 12mm x 24mm x 2.5mm Flat Washers
- x4 8mm Hex Nuts
- x2 10mm Hex Nuts
- x1 4mm Hex Key
- x1 5mm Hex Key
- x1 6mm Hex Key
- x2 6mm Lock Washers
- x4 8mm Lock Washers
- x2 10mm Lock Washers
- x8 12mm Lock Washers
- x3 8mm Nylon Lock Nuts
- x2 10mm Nylon Lock Nuts
- x4 8-1.25mm x 25mm Button Head Bolts
- x2 10mm x 1.5mm x 30mm Button Head Bolts
- x5 6-1.0mm x 20mm Button Head Combo Bolts







Light Bar Inner Box

- x1 Light Bar with Mounting Hardware
- x1 Connector Cable
- x1 DT Connector Wiring Harness

Parts List




TOOLS REQUIRED


 <p>Ratchet</p>	 <p>Extensions</p>
 <p>10mm Socket 13mm Socket 14mm Socket 16mm Socket</p>	 <p>Wrench</p>
 <p>Plastic Cutting Tool</p>	 <p>Clip Remover Tool</p>




(Fig 3) Remove the 13 clips from the plastic cover on top of radiator to remove the cover



(Fig 4) Cover removed




(Fig 5) Remove clips to release grille from cross member




(Fig 6) Remove clips on each side to release grille from upper section

STEP 1 REMOVE FACTORY FRONT BUMPER ASSEMBLY


Follow (Figs 1 – 12) to remove Front Bumper Assembly.




(Fig 1) Remove hardware attaching bottom of plastic bumper cover



(Fig 2) Remove hardware attaching ends of plastic bumper cover along wheel openings



(Fig 7) Remove screw at upper center section




(Fig 8) Remove splash guard by removing indicated fasteners




(Fig 9) Carefully remove bumper by starting at sides and moving towards center



(Fig 10) Remove crash bar and frame extensions by uninstalling four factory bolts from the bracket face plate shown in (Fig 13)



(Fig 11) Remove factory hard plastic on both sides by removing clips indicated by the arrow




(Fig 12) Bumper cover, crash bar, and frame extensions removed




(Fig 12a) Optional: Use provided Zip Ties to organize any wiring and tubing as needed.

STEP 2 WINCH TRAY & A/C LINE


Follow (Figs 13 – 16) to install Winch Tray and relocate AC Line.




(Fig 13) Mount Winch Tray to frame using OE Factory Bolts previously removed. Mount winch onto tray if available.




(Fig 14) At upper cross member Driver Side, remove bolts holding AC line bracket.




- (1) 6mm x 40mm Hex Bolt
- (1) 6mm Lock Washer
- (1) 6mm x 12mm x 1.6mm Flat Washer
- (2) Relocation Wedges



(Fig 15) Reattach bracket between the relocation wedges and fasten with replacement hex bolt (Driver Side)




- (1) 6mm x 40mm Hex Bolt
- (1) 6mm Lock Washer
- (1) 6mm x 12mm x 1.6mm Flat Washer
- (2) Relocation Wedges




(Fig 16) Repeat for Passenger side bracket

STEP 3 TRIMMING BUMPER COVER


Follow (Figs 17 - 21) to trim off Lower section of the Factory Bumper Cover.




(Fig 17) Locate end of bend line on back of plastic bumper cover (Driver/Left)



(Fig 18) Draw a reference line across the back of the cover connecting the two points pictured




(Fig 19) Draw a horizontal cut line 1-3/8" above the reference line




(Fig 20) Draw a vertical cut line following the bend lines (along the arrows) and up to the horizontal cut line




(Fig 22) Remove tape covering threaded hole in end of crossmember on both sides




(Fig 21) Trim bumper cover along dashed cut lines with a plastic cutting tool



(Fig 23) Attach Driver/Left Mounting Bracket to threaded hole in crossmember




(Fig 21a) Optional: Use provided Edge Trim to seal any sharp edges as a result of the trimming.




(Fig 24) Attach Driver/Left Mounting Bracket to the back of the Winch Tray and the Support Bracket to the front of it


STEP 4 INSTALLING MOUNTING BRACKETS

Follow (Figs 22 - 33) to mount the Brackets and reinstall the Bumper Cover.






(Fig 25) Driver/Left Mounting Bracket and Support Bracket installed




- (1) 12-1.25mm x 30mm Hex Bolt
- (1) 12mm Lock Washer
- (1) 12mm Flat Washer



(Fig 26) Attach Passenger/Right Mounting Bracket to threaded hole in crossmember

- (1) 10mm x 40mm Hex Bolt
- (2) 10mm x 30mm Large Flat Washers
- (1) 10mm Lock Washer
- (1) 10mm Hex Nut



(Fig 27) Attach Passenger/Right Mounting Bracket to the back of the Winch Tray and the Support Bracket to the front of it




(Fig 28) Passenger/Right Mounting Bracket and Support Bracket installed




(Fig 29) Carefully reinstall the plastic bumper cover with original hardware in front of Winch Tray



- (1) 8mm x 25mm Hex Bolt
- (2) 8mm x 24mm Flat Washers
- (1) 8mm Nylon Lock Nut




(Fig 30) Bolt together the Wheel Well Liner, Passenger/Right Support Bracket, and Bumper Cover



(Fig 31) Wheel Well Liner, Support Bracket, and Bumper Cover attached together



(Fig 32) Bolt together the Wheel Well Liner, Driver/Left Support Bracket, and Bumper Cover




(Fig 33) Wheel Well Liner, Support Bracket, and Bumper Cover attached together

Note:


Brackets, Hardware, Light Bar, Connector Cable & DT Connector Wiring Harness are inside the B1472 inner carton.

Mount the LED Light Bar with provided Brackets and Hardware from the inner carton. Install the Connector Cable and attach the DT Connector Wiring Harness. Then feed the Wire Switch through the firewall grommet near the driver side.


Go over the separate **Diagram** for detailed layout and specification of the Wiring Harness.



(Fig 34) Install the Light Bar with the provided hardware and bracket from the light bar package



(Fig 35) Install Passenger Side and Driver Side LED Light Bar Brackets with included HW




(Fig 36) If you plan on installing the optional Bull Nose, remove the 2 Rubber Covers on top of bumper on each side

STEP 5 **INSTALLING FRONT BUMPER**

Follow (Figs 34 – 43) to install Center Bumper Guard.


INSTALLING THE LIGHT BAR

- (2) 8mm x 25mm Button Head Bolts
- (4) 8mm x 24mm Flat Washers
- (2) 8mm Lock Washers
- (2) 8mm Hex Nuts



(Fig 37) Attach the optional Bull Nose to Center Bumper Guard

- (3) 12mm x 40mm Hex Bolt
- (3) 12mm x 24mm x 3mm Flat Washers
- (3) 12mm Lock Washer




(Fig 38) Mount the Center Bumper Guard to Winch Tray on both sides




(Fig 39) Center Bumper Guard mounted

(Fig 40) Attach Skid Plate to Center Bumper Guard and Threaded Inserts on the vehicle




(5) 6-1.0mm x 20mm Combo Button Head Bolts



(Fig 41) Skid Plate installed

- (2) 10mm x 30mm Button Head Bolts
- (4) 10mm x 20mm x 2mm Flat Washers
- (2) 10mm Nylon Lock Nuts



(Fig 42) Attach license plate bracket onto Center Bumper Guard



(Fig 43) Installation complete