



TYGER HITCH

TG-HC2F333B

Scan to Download the Latest Digital Version



BEFORE INSTALLATION



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES




Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- x1 Receiver Towing Hitch
- x4 12-1.75mm x 110mm Hex Bolts
- x4 12mm Nylon Lock Nuts
- x1 Harness Bracket
- x8 12mm x 32mm x 3mm Flat Washers
- x1 Plastic Hitch Cover

Parts List




TOOLS REQUIRED



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION

STEP 1

Locate the mounting holes in the frame crossmember behind the rear bumper (Fig 1).





STEP 2

Carefully unwrap the Receiver Hitch. Line up the holes in the Hitch with the crossmember.


STEP 3

Attach the Receiver Hitch and Harness Bracket to the crossmember with the included (4) 12mm x 110mm Hex Bolts, (8) 12mm Flat Washers and (4) 12mm Nylon Lock Nuts (Figs 2 & 3). **NOTE:** Insert the Hex Bolts from the front of the crossmember through the back. Leave hardware loose at this time.



STEP 4

Center and adjust the Receiver Hitch and fully tighten all hardware (Fig 4).



(Fig 4) Receiver Hitch and Harness Bracket installed

STEP 5

Attach the trailer harness to the Trailer Connection Tab, if installed.

STEP 6

Do periodic inspections of the installation to make sure that all hardware is secure and tight.