



## TYGER LanderX

TG-LX3J82628

### BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT:

[WWW.TYGERAUTO.COM/CONTACT](http://WWW.TYGERAUTO.COM/CONTACT)

### TORQUE VALUES

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126


- x1** Driver/Left TYGER LanderX **[D]**
- x1** Passenger/Right TYGER LanderX **[P]**
- x1** Driver/Left Front Mounting Bracket **[A]**
- x1** Driver/Left Center Mounting Bracket **[B]**
- x1** Driver/Left Rear Mounting Bracket **[C]**
- x1** Passenger/Right Front Mounting Bracket **[D]**
- x1** Passenger/Right Center Mounting Bracket **[E]**
- x1** Passenger/Right Rear Mounting Bracket **[F]**
- x1** Driver/Left Front Support Bracket **[G]**
- x2** Driver/Left Center/Rear Support Brackets **[H]**
- x1** Passenger/Right Front Support Bracket **[J]**
- x2** Passenger/Right Center/Rear Support Brackets **[K]**
- x6** 8mm Lock Washers
- x24** 6mm x 22mm x 2mm Flat Washers
- x6** 8mm x 28mm x 3mm Flat Washers
- x6** 6mm Nylon Lock Nuts
- x6** 10mm Nylon Lock Nuts
- x12** 6-1.0mm x 25mm Hex Bolts
- x6** 8-1.25mm x 35mm Hex Bolts
- x6** 10-1.5mm x 30mm Hex Bolts
- x12** 10mm x 24mm x 2.2mm Flat Washers
- x12** 8-1.25mm x 25mm Combo Bolts

Parts List




### Top View

**ATTENTION:** Refer to **[D]** and **[P]** labelling on the side of the tubes to determine Driver and Passenger LanderX

#### **[P]** Passenger Side LanderX




#### **[D]** Driver Side LanderX





- Hex Bolts**
  - x12** 6-1.0mm x 25mm Hex Bolts
  - x6** 8-1.25mm x 35mm Hex Bolts
  - x6** 10-1.5mm x 30mm Hex Bolts
- Lock Washers**
  - x6** 8mm Lock Washers
- Flat Washers**
  - x24** 6mm x 22mm x 2mm Flat Washers
  - x6** 8mm x 28mm x 3mm Flat Washers
  - x12** 10mm x 24mm x 2.2mm Flat Washers
- Combo Bolts**
  - x12** 8-1.25mm x 25mm Combo Bolts
- Nylon Lock Nuts**
  - x12** 6mm Nylon Lock Nuts
  - x6** 10mm Nylon Lock Nuts

Reference the letters printed on the brackets to determine mounting locations




**D** Driver Side LanderX




**P** Passenger Side LanderX

**Bottom View**







**D** Driver Side LanderX




**P** Passenger Side LanderX

## TOOLS REQUIRED




## STEP 1 MOUNTING BRACKETS



Follow (Fig 1 – 12) to attach the Mounting Brackets to the Driver Side.







### 📍 Driver-side Front Mounting Area





**Driver-side Center Mounting Area**




**Driver-side Rear Mounting Area**





## STEP 2 MOUNTING RUNNING BOARD

Follow (Fig 13) to install the running board.



## STEP 3 PASSENGER SIDE

Repeat **STEPS 1-2** for passenger side installation.


Use Front Mounting Bracket [D] instead of [A];

Use Center Mounting Bracket [E] instead of [B];

Use Rear Mounting Bracket [F] instead of [C];

Use Front Support Bracket [J] instead of [G];

Use Center/Rear Support Brackets [K] instead of [H].



## STEP 4

Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

