



TYGER LanderX

TG-LX3T82428

BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT



TORQUE VALUES

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- x1** Driver/Left TYGER LanderX
- x1** Passenger/Right TYGER LanderX
- x1** Driver/left Front Bracket (A)
- x2** Driver/Left Center/Rear Brackets (B)
- x1** Passenger/Right Front Bracket (C)
- x2** Passenger/right Center/Rear Brackets (D)
- x12** 8mm Lock Washers
- x12** 8-1.25mm x 25mm Combo Bolts
- x12** 8-1.25mm x 30mm Hex Bolts
- x12** 8mm x 24mm x 2mm Flat Washers


Parts List

Reference the letters printed on the brackets to determine mounting locations



Bottom View

ATTENTION: Refer to the **D** or **P** labelling on the tubes to determine the Driver or Passenger side steps.



PROCEDURE:


REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.

STEP 1

Start the installation under the driver/left side of the vehicle. Locate the 2 threaded holes in the bottom of the body (Fig 1).


NOTE: Threaded holes might be covered with plugs. Remove plugs from threaded holes.

Driver/left Side Installation Pictured




(Fig 1) Driver/left front mounting location. Remove plugs from threaded holes (arrows)

Driver/left Side Installation Pictured



(Fig 2) Attach Driver/Left Front Bracket (A) to threaded holes in floor



(Fig 3) Driver/Left Front Bracket (A) installed


STEP 2

Select the driver/left "A" Front Bracket (Fig 2). Attach the Bracket to the (2) threaded holes with (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers (Fig 3). Snug but DO NOT fully tighten the hardware.


STEP 3

Move to the center mounting location (Fig 4). Select (1) driver/left "B" Center/rear Bracket (Fig 5). Repeat **STEPS 1 & 2** to attach the Bracket to the floor (Fig 6).


Driver/left Side Installation Pictured



(Fig 4) Driver/left center mounting location



(Fig 5) Attach driver/left center/rear Brackets (B) to center and rear mounting locations




(Fig 6) Driver/left Center Bracket (B) installed


STEP 4

Continue on to the last pair of threaded holes close to the rear wheel opening (Fig 7). Repeat **STEPS 1-3** to attach the remaining driver/left "B" Center/rear Bracket (Fig 8).

Driver/left Side Installation Pictured



(Fig 7) Driver/left rear mounting location





(Fig 8) Driver/left Rear Bracket (B) installed


STEP 5

Carefully unwrap the TYGER LanderX. Select the driver/left TYGER LanderX. Note "D" on back of tube. Carefully position the Side Step up to the (3) Brackets. **IMPORTANT:** DO NOT slide, (front to back or rotate), the TYGER LanderX against the Brackets or damage to the finish may result. Attach the TYGER LanderX to the Brackets with (6) 8mm x 25mm Combo Hex Bolt assemblies (Figs 9-12). DO NOT fully tighten hardware.

Driver/left Side Installation Pictured



(Fig 10) Attach driver/left TYGER LanderX to Front Bracket



STEP 6

Level and adjust the TYGER LanderX and tighten all hardware.

STEP 7

Repeat **STEPS 1-6** to install the passenger/right TYGER LanderX.

STEP 8

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

